



CV503-WP

All-Weather HD Miniature Camera

User Manual

Table of Contents

Table of Contents 01

1. Menu Structure 02

2. OSD Joystick and Button..... 04

3. WB Control 05

4. AE Control 06

5. Day / Night 07

6. Image Control 08

7. Special 09

8. Setup 10

9. Reset 11

10. Exit 12

11. Troubleshooting 13

Warranty END

1. Menu Structure

SETUP	SUB MENU	SUB MENU
WB CONTROL	ATW	
	ONE PUSH	
	INDOOR	
	OUTDOOR	
	MANUAL	BLUE
		RED
AE CONTROL	AUTO	AGC MAX
		SENS UP
		AE BRIGHT
		FLK CONTROL
		LENS MODE (DC IRIS ONLY)
	SHUT FIX	SHUTTER
		AGC MAX
		SENS UP
		AE BRIGHT
		FLK CONTROL
	AGC FIX	AGC
		AE BRIGHT
		FLK CONTROL
		LENS MODE (DC IRIS ONLY)
MANUAL	SHUTTER	
	IRIS	
	AGC	
	FLK CONTROL	
	LENS MODE (DC IRIS ONLY)	
DAY / NIGHT	DAY	
	NIGHT	NIGHT COLOR
IMAGE CONTROL	LENS SHADING	
	CONTRAST	
	BRIGHTNESS	

SETUP	SUB MENU	SUB MENU
IMAGE CONTROL	SATURATION	
	HUE	
	EDGE ENHANCE	
	AUTO SATURATE	
	AUTO EDGE	
	BLACK WHITE LEVEL	
	GAMMA CORRECT	
	DNR	DNR MODE DNR LEVEL
SPECIAL	DZOOM	
	DEFOG	
	DIS	
	BACKLIGHT	
	BINNING	
	DEFECT PIXEL	
	DISP FUNCTION	
	WDR	
	FLICKER DETECT	
	PRIVACY	
SETUP	CAM TITLE	
	COMMUNICATION	RS-485/ID
	SYSTEM INFO	
	OUTPUT FORMAT	
RESET	USER/FACTORY	
EXIT		

2. OSD Joystick and Button



I/O Cable (included in box) for CV503, CV506, CV344, CV346

- 1. SET Used to access the menu and confirm selection.
- 2. UP Used to move the cursor up.
- 3. DOWN Used to move the cursor down.
- 4. LEFT Used to move the cursor left and change the value
- 5. RIGHT Used to move the cursor to the right and change the value.

Press SET button to access the Main Menu

Use the UP & DOWN buttons to select the desired item.

MENU

WB CONTROL >

AE CONTROL >

DAY/NIGHT >

IMAGE CONTROL >

SPECIAL >

SETUP >

RESET >

EXIT >


Use the LEFT & RIGHT buttons to change the sub-item.

> Icon indicates "Press OSD button" or "Enter Sub Menu"

3. WB CONTROL

Select WB CONTROL using the UP or DOWN button. You can change between AUTO, ATW, PUSH, and MANUAL using the LEFT or RIGHT buttons.


- **ATW:** Continuously adjusts camera color balance in accordance with any change in color temperature. Compensates for color temperature changes within the range of 1,900°K to 11,000°K.
- **ONE PUSH:** Color temperature will be manually adjusted by pushing the OSD button. Place the white paper in front of the camera when OSD button is pressed to obtain the optimum result.
- **MANUAL:** Select this to fine-tune White Balance manually.
You can adjust the blue and red tone level manually.
 1. **BLUE:** Adjust the Blue tone of the image. (0~100)
 2. **RED:** Adjust the Red tone of the image. (0~100)
- **INDOOR:** Select this to adjust white balance to indoor lighting condition.
- **OUTDOOR:** Select this to adjust white balance to outdoor lighting condition.



1. Adjust White Balance first by using the ATW mode before switching to MANUAL mode.
2. White Balance may not work properly under the following conditions. In this case, select the ATW mode.
 - When the ambient illumination of the subject is dim.
 - If the camera is directed towards a fluorescent light or is installed in place where illumination changes dramatically, the White Balance operation may become unstable.

4. AE CONTROL

Select AE CONTROL using the UP or DOWN button. You can select one sub-mode using the UP or DOWN buttons.




- **AUTO:** Adjusts the exposure level automatically. Detailed fine tuning options are available under this menu.
- **SHUT FIX:** Provides more detailed shutter speed options. All other controls are tuned for the selected shutter speed.
- **AGC FIX:** Provides more detailed gain option. All other controls are tuned for the selected gain value.
- **MANUAL:** Adjusts the exposure level manually.
 1. **SHUTTER:** Speed can be set at auto or manual. (1/30~1/10,000)
 2. **IRIS SPEED:** Electronic Iris speed can be controlled, for DC Iris lens only. (0~5)
 3. **AGC:** Electronic Iris speed can be controlled, for DC Iris lens only. (0~5)
 4. **AGC MAX:** Used to set maximum gain value to control the video noise caused by Auto Gain Control. (Off, Low, Middle, High, DMIN, DMID, DMAX)
 5. **SENS UP:** Controls the digital slow shutter to allow extra light into the camera and adjust the picture quality. (Off, x2~x10)
 6. **AE BRIGHT:** Select this to adjust auto exposure brightness levels. (0~10)
 7. **LENS MODE:** Lens setting will be optimized for selected environment, for DC Iris lens only.
 8. **FLK CONTROL:** Provides a proper image sensor frequency to match the power frequency in order to minimize video flicker.

5. DAY / NIGHT


Select DAY / NIGHT using the UP or DOWN button. You can select one sub-mode from AUTO, COLOR, and NIGHT using the UP or DOWN buttons.

- **MODE:** Auto, Day, Night
 - **AUTO:** Camera will change between day and night mode when the light condition changes.
 - **DAY:** Camera will stay on day mode.
 - **NIGHT:** Camera will stay on night mode.
- **DELAY [SEC]:** Delay time of changing mode can be adjusted from this menu.
- **D->N LEVEL:** Change the camera threshold value of Day to Night mode.
- **N->D LEVEL:** Change the camera threshold value of Night to Day mode.
- **NIGHT COLOR:** Change the camera threshold value of Night to Day mode.



6. IMAGE CONTROL

Select IMAGE CONTROL using the UP or DOWN button. You can select LENS SHADING, CONTRAST, HUE, And EDGE ENHANCE using the UP or DOWN buttons.




- **LENS SHADING:** Corrects inconsistent brightness level in the image.
- **CONTRAST:** Adjust the image contrast level value.
- **BRIGHTNESS:** Adjust the image brightness level value.
- **SATURATION:** Adjust the image saturation level value.
- **HUE:** Adjust the image hue level value.
- **EDGE ENHANCED:** Adjust the image sharpness level.
- **AUTO SATURATE:** Decrease saturation automatically when noise scene is detected.
- **AUTO EDGE:** Adjust line sharpness level automatically.
- **BLACK WHITE LEVEL:** Adjust the image black level value.
- **GAMMA CORRECT:** Adjust the image output gamma level.
- **DNR:** Reduces the video noise at low ambient light.

Select the DNR level from OFF, LOW, MIDDLE, and HIGH using the LEFT or RIGHT button.

7. SPECIAL

Select **SPECIAL** using the UP or DOWN button.

You can select **DEFOG**, **MOTION DETECT**, **BACKLIGHT**, **DEFECT PIXEL**, and **FLICKER DETECT** using the UP or DOWN buttons.




- **DZOOM:** Digitally zoom the video by the desired ratio.
- **DEFOG:** This feature will help increase visibility in extreme weather conditions, such as fog, rain or in a very strong luminous intensity.
- **DIS:** This feature enables digital image stabilization.
- **BACKLIGHT:** Adjust backlight compensation by choosing either BLC HLM from this menu.
- **BINNING:** Enable or disable pixel binning.
- **DEFECT PIXEL:** Advanced defective pixel correction menu.
- **DISP FUNCTION:** Display effect such as freeze mirror, rotation, and style can be applied from this menu.
- **WDR:** This feature enables user to view both object and background more clearly when background is too bright.
- **FLICKER DETECT:** Adjust the image sensor frequency to match the power frequency.
- **PRIVACY:** Mask an area you want to hide on the screen by applying the privacy zones.

8. SETUP

CAMERA setup can be adjusted from this menu.

You can select **CAMERA ID**, **Communication**, **System Info**, and **Output Format** using the UP or DOWN buttons.



- **CAM TITLE:** Camera title can be turned ON or OFF.
- **COMMUNICATION:** VISCA communication can be adjusted.
 1. **CAM ID:** Camera ID can be setup. (0~7)
 2. **ID DISPLAY:** Camera ID display can be displayed.
 3. **BAUDRATE:** Camera baudrate can be set. (2400, 4800, 9600, 19200, 38400)
- **SYSTEM INFO:** Camera information can be found under this menu.
- **OUTPUT FORMAT:** Camera resolution and frame rate can be set. (1080 by default)

Select the **FRAME RATE** using the LEFT or RIGHT buttons.

Available Frame Rates are:

1920 x 1080p 60, 59.94, 50, 30, 29.97, 25, 24, 23


1920 x 1080i 60, 59.94, 50

1280 x 720p 60, 59.94, 50

9. RESET

Select *RESET* using the *UP* or *DOWN* buttons.

- **RESET:** Reset the camera settings the factory defaults or user setting value.



- **ON:** Set the camera setting to either “FACTORY” or “USER” of “CHANGE” menu. Make sure to select the right mode from “CHANGE” before defaulting the camera.


- **RESET MODE:** Select the desired setting mode.

Select from *USER* or *FACTORY* using the *LEFT* or *RIGHT* button.

1. **USER:** Select “USER” if setting value user saved last is needed.
2. **FACTORY:** Select “FACTORY” if factory default setting is needed.
“FRAME RATE”, “CAM ID”, and “BAUDRATE” will not change.

10. EXIT

Select *EXIT* using the *UP* or *DOWN* button.



- **SAVE:** Exit the setup after saving the value changes.

11. TROUBLESHOOTING

Before sending the camera for repair, please check below to make sure that the camera is installed correctly. If it still does not perform adequately, please consult with your supplier.

Problem	Solution
Nothing appears on the screen.	<ol style="list-style-type: none"> 1. Check that all connected devices are powered on. 2. Confirm that the voltage is correct. 3. Confirm that the power supply provides enough current to power the camera. 4. Check that all video cables are properly connected.
The picture is not clear.	<ol style="list-style-type: none"> 1. Check that your monitor is correctly adjusted. 2. Confirm that the glass in front of the lens is clean. If there is dust, dirt or fingerprints on the glass, the image quality will be affected. 3. To clean the glass, use a soft, dry and non-abrasive cloth or a commercially available lens cleaning set. 4. Adjust the focus by carefully rotating the threaded M12 lens.
The picture has interference.	<ol style="list-style-type: none"> 1. Ensure that the camera is not positioned near a high voltage source, such as a power generator. 2. Check that the connected BNC cable is terminated properly. 3. Check that all video cables are properly connected.
The picture is flickering continually.	<ol style="list-style-type: none"> 1. Check the termination and set the impedance at 75Ω properly. 2. Ensure that the camera is not pointing towards the Sun or any light source. 3. Check the performance of any intermediate devices. 4. Check if the distance of the video cable exceeds the maximum transferable limitation.

Warranty

Marshall Electronics warranties to the first consumer that this device will, under normal use, be free from defects in workmanship and materials, when received in its original container, for a period of two years from the purchase date. This warranty is extended to the first consumer only, and proof of purchase is necessary to honor the warranty. If there is no proof of purchase provided with a warranty claim, Marshall Electronics reserves the right not to honor the warranty set forth above. Therefore, labor and parts may be charged to the consumer. This warranty does not apply to the product exterior or cosmetics. Misuse, abnormal handling, alterations or modifications in design or construction void this warranty. No sales personnel of the seller or any other person is authorized to make any warranties other than those described above, or to extend the duration of any warranties on behalf of Marshall Electronics, beyond the time period described above.

Due to constant effort to improve products and product features, specifications may change without notice.

Marshall

20608 Madrona Avenue, Torrance, CA 90503

Tel: (800) 800-6608 / (310) 333-0606 • Fax: 310-333-0688

www.marshall-usa.com

support@marshall-usa.com