

Technical Support:

Telephone	(818) 772-9100
	(800) 545-6900

Fax (818) 772-9120

Technical Support Hours:

8:00 AM to 5:00 PM Monday through Friday Pacific Time

Write To:

Gefen, LLC C/O Customer Service 20600 Nordhoff St. Chatsworth, CA 91311

support@gefen.com www.gefen.com

Notice

Gefen, LLC reserves the right to make changes in the hardware, packaging and any accompanying documentation without prior written notice.

DVI Splitter is a trademark of Gefen, LLC All trademarks are the property of their respective owners.

© 2010 Gefen, LLC, All Rights Reserved

- 1. Introduction / Operation Notes
- 2. Features
- 3. Panel Descriptions
- 4. Connecting and Operating the DVI Splitter
- 5. Rack Ears Installation Diagram
- 6. Specifications
- 7. Warranty

Gefen's 1:4 DVI Distribution is a distribution hub that sends the same DVI graphics source to up to four DVI digital displays (flat panels or projectors). It is a reliable solution that accommodates four digital video displays at the same time, creating a multi-viewing environment that maintains the highest resolution video at all times.

How It Works

The DVI Splitter is connected with a DVI (male to male) cable from the DVI graphic source to the 1:4 DVI Splitter input. There are four DVI outputs. DVI output one is the primary connection and is used for the main display. DVI outputs two through four follow the main display.

OPERATION NOTES

READ THESE NOTES BEFORE INSTALLING OR OPERATING THE DVI SPLITTER


- Display information (EDID) is sent from the display connected to DVI Output Port 1 to the source connected to the DVI Splitter. (See note on page 4 for additional information)
- The DVI Splitter is not HDCP compliant
- The DVI Splitter will only output a DVI-D (DVI Digital) signal
- Compatible with all DVI displays

Features

- · Connects computers with DVI video to up to four DVI monitors/projectors
- Allows simultaneous display
- Maintains video resolutions up to the highest DVI single link resolution of 1920 x 1200
- Supports DDWG standard for DVI monitors

Includes:

- (1) DVI Splitter
- (1) 6ft DVI cable (M-M)
- (1) 5V DC Power Supply
- (1) Rack Ears
- (1) User Manual



*See Note on page 4




How to Connect the DVI Splitter

- 1 Connect the supplied cable from the computer DVI source into the DVI input port of the DVI Splitter.
- 2 Connect the user supplied cable(s) from your display(s) into the DVI output port(s)* of theDVI Splitter.
- **3** Plug the 5V DC power supply into the DVI Splitter.

NOTE: *Display information (EDID) is sent from the display connected to HDMI Output Port 1 to the source connected to the DVI Splitter. The source will output resolutions and timings according the EDID that is being fed by the DVI Splitter. Therefore, all of the connected displays must be capable of accepting the timings and resolution output by the source. It is recommended that the display with the lowest native resolution be connected to DVI output port 1. This is to ensure that a compatible video signal will be able to be displayed on all connected monitors.

Rack mount ears are provided for installation of this unit into a 1U rack mount space.

- 1. Locate the side screws on the unit.
- 2. Remove the front 2 screws that are located closest to the front of the unit.
- 3. Using the removed screws, screw the rack mounting bracket into the unit.
- 4. Repeat the procedure on the opposite side of the unit.



SPECIFICATIONS

Video Amplifier Bandwidth	165 MHz
Input Video Signal	1.2 Volts p-p
Input DDC Signal	5 Volts p-p (TTL)
Single Link Range (Max. Resolution)	
Input Connector Type	DVI-I 29 pin female (DVI-D digital only)
Output Connector Type	DVI-I 29 pin female (DVI-D digital only)
Power Consumption	
Power Supply	5V DC @ 5W max.
Rack Mountable	1U Rack Space
Dimensions	17.1"W x 1.7"H x 4.2"D
Shipping Weight	

Gefen warrants the equipment it manufactures to be free from defects in material and workmanship.

If equipment fails because of such defects and Gefen is notified within two (2) year from the date of shipment, Gefen will, at its option, repair or replace the equipment, provided that the equipment has not been subjected to mechanical, electrical, or other abuse or modifications. The two year warranty is only valid on new products purchased as of January 2007. All products purchased before this date still retain their 1 year warranty.

Equipment that fails under conditions other than those covered will be repaired at the current price of parts and labor in effect at the of repair. Such repairs are warranted for ninety (90) days from the day of reshipment to the Buyer.

This warranty is in lieu of all other warranties expressed or implied, including without limitation, any implied warranty or merchantability or fitness for any particular purpose, all of which are expressly disclaimed.


- 1. Proof of sale may be required in order to claim warranty.
- 2. Customers outside the US are responsible for shipping charges to and from Gefen.
- 3. Copper cables are limited to a 30 day warranty and cables must be in their original condition.

The information in this manual has been carefully checked and is believed to be accurate. However, Gefen assumes no responsibility for any inaccuracies that may be contained in this manual. In no event will Gefen , be liable for direct, indirect, special, incidental, or consequential damages resulting from any defect or omission in this manual, even if advised of the possibility of such damages. The technical information contained herein regarding the DVI Splitter features and specifications is subject to change without notice.

For the latest warranty coverage information, please visit Gefen's Warranty web page at http://www.gefen.com/kvm/aboutus/warranty.jsp

PRODUCT REGISTRATION

Please register your product online by visiting Gefen's web site at http://www.gefen.com/kvm/Registry/Registration.jsp



20600 Nordhoff St., Chatsworth CA 91311 1-800-545-6900 818-772-9100 fax: 818-772-9120 www.gefen.com support@gefen.com













